



Using the VK-X3000 Series for the First Time

3D Surface Profiler

Quick Start Guide

- Gathering New Film Thickness Data -

Introduction

Thank you for your purchase of the VK-X3000 Series 3D Surface Profiler.

This manual describes the measurement method for film thickness, such as permeable films and glass, as well as transparent coatings.

Note that there are two methods for measuring film thickness: laser confocal and spectral interference.

Contents

Chapter 1 Before Starting Operation	3
1-1 Understanding the Difference of the Measurement Methods	4
1-2 Understanding the Operation Flow	5
Chapter 2 Preparation for Measurement	7
2-1 Connecting the Spectrometer	8
2-2 Starting the Viewer Application	9
2-3 Adjusting the Magnification and Focus	10
Chapter 3 Laser Film Thickness Measurement	11
3-1 Using Laser Film Thickness	12
3-2 Analyzing Laser Film Thickness	17
Chapter 4 Spectral Film Thickness Measurement	19
4-1 Using Spectral Film Thickness	20
4-2 Analyzing Spectral Film Thickness	27



Chapter 1

Before Starting Operation




There are differences between the laser film thickness and spectral film thickness as follows.


● **Spectral film thickness**
Spectral film thickness is an optional function that can be purchased. VK-T300 hardware is required.

Film thickness measurement method	Laser film thickness	Spectral film thickness																	
<p>Principle</p>	<p>If the object is a transparent target, the transmitted light will penetrate the surface and reflect off of the bottom layer. As the result, the thickness of the transparent target can be determined by calculating the difference between the two surfaces.</p> 	<p>When illuminating a transparent target with light, there are two reflections that occur; light that reflects from the surface of the film (R1) and light that refracts inside the film and reflects off of the bottom layer (R2). R1 and R2 overlap and experience constructive and destructive interference.</p>  <p>Spectral film thickness then calculates the film thickness using this interference pattern, understanding that this interference changes depending on the thickness of the film.</p>																	
<p>Film thickness to be measured</p>	<p>Approx. 2 μm - The film thickness that can be measured depends on each lens magnification.</p> <table border="1" data-bbox="288 1234 679 1417"> <thead> <tr> <th>Model</th> <th>Objective lens</th> <th>Measurable film thickness value</th> </tr> </thead> <tbody> <tr> <td rowspan="3">VK-X3100</td> <td>50x</td> <td>2μ -</td> </tr> <tr> <td>20x</td> <td>12μ -</td> </tr> <tr> <td>10x</td> <td>50μ -</td> </tr> <tr> <td rowspan="3">VK-X3050</td> <td>50x</td> <td>3.5μ -</td> </tr> <tr> <td>20x</td> <td>20μ -</td> </tr> <tr> <td>10x</td> <td>80μ -</td> </tr> </tbody> </table>	Model	Objective lens	Measurable film thickness value	VK-X3100	50x	2 μ -	20x	12 μ -	10x	50 μ -	VK-X3050	50x	3.5 μ -	20x	20 μ -	10x	80 μ -	<p>Approx. 0.1 μm - 5.0 μm</p>
Model	Objective lens	Measurable film thickness value																	
VK-X3100	50x	2 μ -																	
	20x	12 μ -																	
	10x	50 μ -																	
VK-X3050	50x	3.5 μ -																	
	20x	20 μ -																	
	10x	80 μ -																	
<p>Recommended objective lens</p>	<p>10x, 20x, 50x *Objective lenses other than those listed above can be used as well, however, check their performance before using them.</p>	<p>10x, 20x, 50x *Objective lenses other than those listed above can be used as well, however, check their performance before using them.</p>																	

The operation flow of the laser film thickness measurement is as follows.




The operation flow of the spectral film thickness measurement is as follows.




Chapter 2

Preparation for Measurement



To perform the spectral film thickness measurement, connect the spectrometer first.

1. Remove the spectrometer out of the case.
2. Connect the USB cable to the Micro-B connector of the spectrometer.



3. Connect the USB cable to the USB connector on the back of the control PC.


When using laser film thickness, this step is not required.

! Point

Perform the connection of the spectrometer before starting the Viewer Application.


To obtain new data, click the icon on the desktop to start [VK-X 3000 Viewer Application].

1. Double-click the [VK-X 3000 Viewer Application] icon on the desktop.




A dialog box confirming movement of the revolver and stage will appear.

2. Click the [Yes] button.




3. The stage will return to origin, and the Viewer Application starts.



Adjust the magnification and focus so that the image of the sample appears properly in the viewing window.


1. Place the sample on the XY stage.
2. Adjust the height of the XY stage.

Turn the focusing handle (Coarse/Fine) to adjust the focus.




3. Focus the objective lens.

On the operation panel, click the [AF] button.



4. Select the objective lens.

Adjust the focus with a desirable lens magnification by repeating Steps 2 to 3.



- The motorized XY stage can accommodate samples up to 70 mm in height and 3.0 kg in weight.
- The standard XY stage can accommodate samples up to 70 mm in height and 5.0 kg in weight.


Chapter 3

Laser Film Thickness Measurement



This section describes the operation procedure for laser film thickness.

1. On the toolbar, click [Film Thickness Measurement].




● **Laser film thickness measurement**

Measure the thickness (film thickness of more than 2 μm) and shape of the top three layers of a transparent target.


2. Click the [Laser film thickness] button.

It will switch to the laser film thickness of the film thickness measurement mode.



3. Adjust the focus using the appropriate lens.

Select the objective lens to be used for the measurement. Next, on the operation panel, click the [AF] button to execute the auto focus.




! Point

When the screen goes dark completely by switching the display image from [Camera] to [Laser], click the auto focus button.


The screen brightness is optimized.

4. Adjust the brightness of the laser.


Switch the displayed image from [Camera] to [Laser].

**5. Next, click the vertical position buttons for the objective lens to move the objective lens upward.**

Move it upward past the top surface of the film to be measured, until the laser image turns black and disappears.


**6. Click the [Upper Limit] button.**

Set the upper limit value of the range to be measured.




7. Click the vertical position buttons for the objective lens to move the objective lens downward.

Move it downward past the bottom surface of the film to be measured, until the laser image turns black and disappears again. Note that you may need to scroll through several reflected layers to get to the bottom surface depending on the sample.




8. Click the [Lower Limit] button.

Set the lower limit value of the range to be measured.




9. Click the [Auto] button.


Optimize the laser brightness within the specified measurement range.



10. Select [Standard (1024 x 768)] in the [Resolution] box.



11. Select [High Precision] in the [Quality] box.




12. Select a pitch as needed.

Normally, the RPD (Real Peak Detection) method is used to detect the focal point position. It's recommended to keep RPD on.

13. Click the [Start Measurement] button.

A confirmation message appears asking whether to perform a preview measurement. Click the [Yes] button.




The preview measurement starts, and the [Laser film thickness preview] window appears.

Make sure that the measured layer (white signal) matches the detected layer (red, light blue, and magenta lines) before performing the measurement.


When the detected layer is not matched, refer to the [Chapter 7](#) of "Viewer Application Reference Manual".

14. Click the [Start Measurement] button.



The film thickness measurement results will be displayed.

15. Click the [Save Measurement Results] button to save the result.



! Point

The [Laser film thickness preview] window appears only for the recommended objective lens with 10x, 20x, or 50x.

For other objective lenses, measurement starts at the same time as the [Start measurement] button is clicked.


! Point

Click the [Analyze] button to display the measurement results in the Multifile Analyzer.

Next, we will analyze the obtained laser film thickness data.


1. Click the [Add data] button, and select the saved measurement data.

The obtained laser film thickness data will appear.




2. Select the surface film thickness.

On the toolbar, click the [Surf. F.T.] button. Alternatively, you can select [Surface film thickness measurement] from the [Measurement] menu.



3. Click to select [2 Points] in [Profile line].


Create a cross section profile using the 12 types of profile tools that appear on the top right of the screen. In this case, select 2 points specification.




The [Area settings] window appears.

4. Click the part where you want to measure the film thickness, and draw a line.

On the top right of the screen, place the cursor over the area where you want to measure the film thickness, then click it. In the lower half of the screen, the film thickness profile at the specified place appears.




5. Click and select [Segment] of [Measurement tool].



6. Specify the start point and end point of the place to be measured.

Specify the place to be measured within the profile screen. Move the cursor over the start point of the place where you want to detect the film thickness, then click it. Next, set a range by specifying an end point.




The measurement results will be displayed.

! Point

To display the correct film thickness value, the index of refraction must be corrected.



Click the [Refractive index correction] button, then enter the refractive index of the film being measured.



Chapter 4

Spectral Film Thickness Measurement



This section describes the operation procedure for the laser film thickness.


1. On the toolbar, click [Film Thickness Measurement].



Measure the thickness (film thickness of more than 2 μm) and shape of the top three layers of a transparent target.


2. Click the [Spec. Film] button.

It will switch to the spectral film thickness of the film thickness measurement mode.




3. Mount the spectroscopy adapter.

Click the [Install adapter] button from the spectral film thickness of the film thickness measurement mode.



The confirm dialog box appears. Click the [OK] button.


4. Click the [Lens] button.



The [Lens replacement] dialog box appears.


5. Select the objective lens to be used, and click the [Remove] button.

Follow the displayed instructions to remove the objective lens.



6. Click the [Close] button, and close the [Lens Replacement] dialog box. Next, the spectroscopy adapter will be mounted on the position where the objective lens has been removed.

Click the [Mount] button.




The [Select Lens] dialog box appears.

! Point


Make sure to confirm the [Spec. adapter] field. The spectroscopy adapter can be mounted only at the mount position displayed as "Mounted".

7. Select the registration of the objective lens for the spectroscopy adapter to be mounted, and click the [Next] button.

Follow the displayed guidance to mount the spectroscopy adapter and objective lens.




8. Follow the on-screen instructions to mount the bracket, and click the [Next] button.




The [Mount adapter] dialog box appears.

9. Follow the on-screen instructions to mount the adapter, and click the [Next] button.



The [Mount Lens] dialog box appears.

10. Follow the on-screen instructions to mount the lens, and click the [Finish] button.




The confirm dialog box appears.



After this, connect the spectroscopy adapter to the spectrometer via the fiber optic cable, then perform reference adjustments.

11. Execute the reference adjustment.

The confirmation dialog box appears, click the [OK] button.




● A note about reference adjustment

The spectral film thickness measurement measures the film thickness from changes in each light wavelength reflected from the measurement object. Therefore, a reference adjustment with a reference mirror (optical flat) and a dark sample is required before the measurement.


12. Set the reference mirror (optical flat) for adjusting the reference for the spectral film thickness. After adjusting the focus, click the [Start Adjustment] button.

Execute the reference adjustment.




● A note about the reference mirror (optical flat)

Use the reference mirror (optical flat) that is supplied with the spectral film thickness unit VK-T300.




13. Set the dark sample for adjusting the reference for the spectral film thickness. After adjusting the focus, click the [OK] button.

The adjustment using the dark sample is performed, and the confirmation dialog box to finish the adjustment appears.




● A note about the dark sample


Use the dark sample that is supplied with the spectral film thickness unit VK-T300.



14. Click the [OK] button.




15. Click the [Close] button in the [Install adapter] window.




The adjustment is complete.

16. Set the sample for the measurement, and adjust the focus.




17. Set the film component in the advanced settings window as needed.

If the film component is one layer, selecting a film material will display [Film thickness preview] and [Degree of fit].




● Advanced settings

In the advanced settings dialog box, setting the base and film thickness material displays the [Film thickness preview] and [Degree of fit] in real time. Note that the measurement is performed without the film component setting if it is the sample with 2 or more layers.




18. Click the [Start Measurement] button.



! Point

Before starting measurement, adjust the focus and brightness to the best conditions.


19. Save the measurement result.



Next, we will see how to analyze the obtained spectral film thickness data.


1. Click the [Add data] button, and select the saved measurement data.

The obtained spectral film thickness data will appear.




2. Select the spectral film thickness measurement.

On the toolbar, click the [Spec. film] button. Alternatively, you can select [Spectroscopy film thickness measurement] from the [Measurement] menu.




3. Click the [Add layer] button in [Layer configuration setting] on the top right of the screen, and enter the layer configuration (material and thickness) of the measured sample.




The [Add layer] window appears.

Select [Material] of the [Add layer] window from the pull-down menu.
In addition, enter the prediction value (design value) of the film.




Click the [OK] button.

The layer of the material selected for the film component is added.




■ Automatic material judgment function

When selecting “Other(Auto)” for material of the [Add layer] window, the material with the highest fit degree from the entire database will be selected automatically.




When selecting “nk-Cauchy” in the analysis model of the [Advanced settings for the optical constant] window, measurement results with higher fit degree can be acquired.



● A note about the material

If the appropriate material does not exist in the material selection of the [Add layer] window, click the [Add material] button to display more materials from the database.




Select the material that you want to add, and click the [Add] button. It is added from the database to the “Show material” list. Click the [OK] button and confirm it.

● Setting of the base and atmospheric air


Double-click the base as needed to change the settings of material etc.

● Advanced settings for the optical constant


When an appropriate material does not exist in the material selection of the [Add layer] window or the [Add material] database, or when the material is an unknown sample, set the best calculation method from the analysis model for calculating optical constants.



4. If multiple layers exist on the sample, add additional layers and confirm the additional materials.




5. Click the [Execute measurement] button.




● **About the measurement result**


When using spectral film thickness measurement, thicker films decrease the period of the waveform, displaying more waves in the chart. This change in waveform allows for thickness measurement.



SiO₂ 2000 nm



SiO₂ 1000 nm



SiO₂ 500 nm

The measurement results of each film thickness appear in the measurement results list.



The film thickness values of each layer are displayed on the bottom right of the screen. In addition, a graph showing the intensity of reflected light for each wavelength is displayed on the bottom left of the screen, and a graph showing the refractive index for each wavelength is displayed on the bottom left of the screen.

MEMO

MEMO

Specifications are subject to change without notice.

KEYENCE CORPORATION

1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku, Osaka, 533-8555, Japan PHONE: +81-6-6379-2211

www.keyence.com/glb

AUSTRIA

Phone: +43 (0)2236 378266 0

BELGIUM

Phone: +32 (0)15 281 222

BRAZIL

Phone: +55-11-3045-4011

CANADA

Phone: +1-905-366-7655

CHINA

Phone: +86-21-3357-1001

CZECH REPUBLIC

Phone: +420 220 184 700

FRANCE

Phone: +33 1 56 37 78 00

GERMANY

Phone: +49-6102-3689-0

HONG KONG

Phone: +852-3104-1010

HUNGARY

Phone: +36 1 802 7360

INDIA

Phone: +91-44-4963-0900

INDONESIA

Phone: +62-21-2966-0120

ITALY

Phone: +39-02-6688220

KOREA

Phone: +82-31-789-4300

MALAYSIA

Phone: +60-3-7883-2211

MEXICO

Phone: +52-55-8850-0100

NETHERLANDS

Phone: +31 (0)40 206 6100

PHILIPPINES

Phone: +63-(0)2-8981-5000

POLAND

Phone: +48 71 368 61 60

ROMANIA

Phone: +40 (0)269 232 808

SINGAPORE

Phone: +65-6392-1011

SLOVAKIA

Phone: +421 (0)2 5939 6461

SLOVENIA

Phone: +386 (0)1 4701 666

SWITZERLAND

Phone: +41 (0)43 455 77 30

TAIWAN

Phone: +886-2-2721-8080

THAILAND

Phone: +66-2-369-2777

UK & IRELAND

Phone: +44 (0)1908-696-900

USA

Phone: +1-201-930-0100

VIETNAM

Phone: +84-24-3772-5555

